



Scoville Glasslux Care and Use Instructions

Welcome to the Scoville family. You will find all the instructions to maximise the performance of your Glasslux product in this booklet.

Hang on to these instructions as you may need them in the future.

Before use remember to remove all packaging, labels and stickers and wash the cookware in warm soapy water before drying thoroughly.

Any queries? Please visit **Scoville.me**

All about safety:

- Never use directly on the hob
- For products with plastic lids, do not put the lid in the oven
- Don't use a damaged dish
- Never put a hot dish in cold water, or a cold dish straight under the grill
- Safe for use between -40°C and 300°C
- When using the item (without its lid) under a grill, leave a space of at least 10cm between the edge of the dish and the grill
- Please exercise caution when using electric mixers in these products
- Avoid using sharp utensils

All about care:

- Wash before use
- Dishwasher safe, handwashing recommended
- In the case of burnt or stuck food, soak in warm, soapy water

All about the 2 year guarantee

- The Scoville 2 year guarantee covers manufacturer defects or materials when the cookware is used in normal, domestic conditions and in accordance with the care and use instructions provided. It does not cover normal wear and tear, commercial use or misuse of the product.
- Your original **proof of purchase or receipt should always be retained** in order to validate the guarantee.
- In the unlikely event of a fault with the cookware, it may be repaired or replaced free of charge with a similar product or one of equivalent value if the original product is no longer available. In the case of a set, only the faulty item/items will be replaced.
- The cost of sending an item for inspection will not be covered under the guarantee.
- Where applicable a replacement or postage charge may be applied.
- This guarantee will only apply to the original purchaser and cannot be transferred to a third party.
- This guarantee will not apply to products purchased from third-party sellers.
- The guarantee only applies when the product has been purchased from one of our authorised retail partners. For the full list of retail partners please visit imperialgb.com/stores/

The following is excluded from the guarantee:

- Damage caused by misuse, abuse, accident, commercial use or neglect.
- Damage caused by failure to comply with the care and use instructions.
- Normal wear and tear including mild discolouration.
- Consequential damage is expressly excluded from this guarantee.

This guarantee does not affect your statutory rights.

The guarantee will only be valid if it is registered within 6 months of the original purchase date.

How to activate your guarantee

Please visit the following link and enter your details:

imperialgb.com/register-guarantee

Terms & conditions

Imperial International Ltd are continuously involved in product development, we therefore reserve the right to change the specification of the items illustrated and described at any time.

The product and packaging have been designed and developed by Imperial International Ltd, which is the sole owner of all intellectual property rights, patent, copyright, design and trademark rights relating to both the product and packaging.

Legal action will be taken against any party found to be reproducing all or any part of the product or the packaging without express written permission from Imperial International Ltd.

Copyright © 2023 Imperial International Ltd.
All Rights Reserved.

Designed & Developed in **Great Britain** By



Imperial International Ltd.
Whiteacres, Whetstone, Leicester,
LE8 6BB, Great Britain

Scoville[®]

is a registered
trademark of
Imperial Great British
Design Ltd.